

INSTALLATION INSTRUCTIONS

Installation of Universal Leather Saddlebag Lock 55-BM009

1. Remove the acorn nuts and turn the lock clockwise until it clicks into place. Remove the backing plate and countersunk screws.
2. Use the backing plate as a template, mark (4) mounting points on the inside of the saddlebag. The top of the lock is best placed 1" from the top of the saddlebag.
3. Use a 1/8" drill bit to drill out the mounting points in the saddlebag. Mount the lock to the saddlebag, with the key in the horizontal position.
4. Mark the area on the saddlebag lid, that needs to be cut away, for the lock cylinder to fit thru. Again, the lock is in the horizontal position. Use the cut-out in the faceplate for the template. Cut the opening in the lid.
5. Remove the (4) screws in the faceplate. Mark and drill the 4 points around the lock cut-out with a 1/8" drill bit. Mount the faceplate to the lid. Place the lock cylinder thru the faceplate and push until the cylinder locks into place.